



NSW RURAL FIRE SERVICE

STICKERBRAND RFS++

NSW RFS BRANDING STICKER PACK

REFLECTIVE TRIM

REFLECTIVE TRIM MUST BE ATTACHED TO YOUR HELMET FOR IT TO MEET AS/NZS1801:1997 TYPE 3 CERTIFICATION.

1. Set your helmet up on something soft to protect the paint finish, then remove the Face Shield.
2. Position helmet so you're looking at the side profile and the front is facing the right.
3. Starting from the rear, place the first piece of reflective trim just under the bottom ridge, about 5mm from the goggle retention strap.
4. Peel the second piece of reflective trim from the sheet, place just under the bottom ridge, 35mm from the front of the helmet. There should be about a 50mm gap between the two pieces of reflective trim (fig 1).
5. Run your thumb over both pieces of reflective trim, pressing out any air bubbles as you go.
6. Rotate helmet and repeat steps 3, 4 & 5 on the other side.

FRONT DECAL

1. Position the helmet so you're looking at the front.
2. The front decal should be positioned in the centre horizontally, with the bottom of the logo sitting 5mm above where the brim begins (fig 2).

