

BEFORE YOU GET STARTED

1. Work on something soft to protect the helmet shell.
2. Clean the helmet with an approved cleaner to ensure the best bond between sticker and shell.

FITTING THE RESCUE EYE PROTECTOR FROM NEW

3. Remove the face shield plugs - one on either side of the helmet.
4. Find the centre of the Battenburg strip. We do this by matching up the two points of the sticker - so they're even.
5. Pinch the sticker at the half way point to form a visible crease.
6. Centre the crease in the sticker with the middle of the ridge at the back of the helmet - about 1cm above the back retention strap. The 'points' of the sticker should be at the top (a).
7. Peel back a little more than half of the backing paper on the sticker - exposing the adhesive.
8. Fit the crease in the sticker to the back ridge. Working from the back to the front apply the sticker carefully so it is above the mounts on the helmet. Work to press out as many creases and bubbles as possible as you wrap the sticker round the helmet.
9. Glide your thumb down the sticker to ensure proper adhesion, pressing out any remaining air bubbles and creases.
10. Remove the rest of the backing paper from the sticker.
11. Carefully wrap and apply the sticker to the other side of the helmet - working to press out as many creases and bubbles as possible.
12. Glide your thumb down the sticker to ensure proper adhesion, pressing out any remaining air bubbles and creases.
13. Run your thumb over the area where the face shield plugs were to find the holes.
14. Using a tool with a pointed end, pierce the sticker to expose the holes.
15. Replace the face shield plugs.



SCAN THE CODE TO WATCH THE VIDEO
DEMONSTRATING THIS PROCESS. DIRECT
LINK: <https://youtu.be/1gbYpy2epQw>

