

### **ADALIT L-90 POWER (PROTO)**

# **USER MANUAL & features**

## **ON/OFF** switch button

### First click

The main LED switches on at maximum intensity.

## Second click

The main LED and the two auxiliary LEDs on the side of the optic switch on. The light beam is more gentle and uniform. Due to the special design of the LedEngine Power Optic, the light gets a greater opening angle that works a **step lighting system**.

### • Third click

The torch switches off.

## Keep hold 4" – STROBE FUNCTION

The main central LED gets on in strobe mode. To return to the previous position, push again On | Off button.

## Keep hold 5" - SAVE BATTERY MODE

The light output decrease and the run time is extended 5 times.

## **RUN TIME INDICATOR**

ON/OFF switch button Green color: < 100% of charge Red color: < 50% of charge

Red color blinking: last 15% of charge

WWW.ADALIT.COM