

## ADALIT L-90 (PROTO)

### USER MANUAL & features

#### ON/OFF switch button

- **First click**  
The two LEDs on at the same time which enables wide and spot light simultaneously. **Step lighting system ON.**
- **Second click**  
Only the LED situated on the flood optic is on and the light gets a greater opening angle. Thanks to the special design of the Led Engine Technology the walking area near to the bearer of the torch gets illuminated – **step lighting system ON.**
- **Third click**  
The torch switches off.
- **Keep hold 2" - BOOSTER**  
BOOSTER function Keeping pushed for two seconds, the LED situated on the focused optic gets on. All power is gathered in one single LED and the light beam reaches the maximum distance and penetration. To return to the previous position, push again On | Off.
- **Keep hold 4" – STROBE FUNCTION**  
The LED situated on the focused optic gets on in strobe mode. To return to the previous position, push again On | Off button.
- **Keep hold 5" - SAVE BATTERY MODE**  
The light output decrease and the run time is extended 5 times.

#### RUN TIME INDICATOR

ON/OFF switch button

Green color: < 100% of charge

Red color: < 50% of charge

Red color blinking: last 15% of charge

[WWW.ADALIT.COM](http://WWW.ADALIT.COM)